


User Guide

Alphanumeric Addressable Keypad/Transceivers incorporates functions of an RF Receiver and a 5800 Transmitter module.



SETTINGS KEY FUNCTION

Press SETTINGS	<p>Displays Settings Menu (options details below):</p> <ol style="list-style-type: none"> 1 Set Time/Date 2 View Event Log 3 Reboot Keypad 4 Set User Code** <ol style="list-style-type: none"> 1. Add a User 2. Delete a User 3. Assign Attr.
-----------------------	--

**The menu-based user code programming feature is only available with certain systems. Check with the system installer for details on features of your system.

Note: For Commercial controls, some of the steps are different than described below. Refer to the system User Guide for details on setting these options.

SETTINGS KEY OPTIONS

Set Time/ Date

1. Press **SETTINGS** and then **1 OFF** to select 'Set Time/Date'.
2. Enter the **Master User Code** at the 'Enter Your Code' prompt and press *****.
3. Press ***** to edit the time and date:
 - Use the number keys to change the time and date shown
 - **1 OFF** = PM, **0** = AM;
 - The navigation keys to move the cursor: ***** = forward, **#** = back.
 - When done, press ***** to save and exit.

View Event Log

1. Press **SETTINGS** and then **2** to select the 'View Event Log'.
2. Enter the **Master User Code** at the 'Enter Your Code' prompt and press *****.
3. Press ***** to move forward or **#** to move backward through events.
4. To exit, press any key except the ***** and **#** keys.

Reboot Keypad

1. Press **SETTINGS** and then **3** to Reboot the keypad. (The keypad beeps and the LEDs flash for several seconds.)

Set User Codes

1. Press **SETTINGS** and then **4 MAX** to select 'Set User Code'.
2. Enter the **Master User Code** at the 'Enter Your Code' prompt and press ***** to see a user option screen.

Add a User: Press **1 OFF** to select 'Add a User'.

- At 'Enter User No.' screen, enter a unique two-digit number and press *****.
- At the 'New User Code' prompt, enter a new four-digit user code and press *****.

Note: Four digit user codes options: 0000 – 9999.

- The keypad will confirm the User setting and exit the Settings mode:

Confirmation	Meaning
Short "ding"	User created successfully
Long "ding"	Error– that user number already has a user code assigned.
No sound	User not created – try again. If necessary, delete the user and try again.

Delete a User: Press **2** to select 'Delete a User'.

- At 'Enter User No.' prompt, enter the desired two-digit number and press *****.
- The keypad will "ding" to confirm the User deletion and exit the Settings mode.

Assign Attributes: Press **3** to select 'Assign Attr.'.

- At 'Enter User No.' screen, enter the desired two-digit user number and press *****.

The Assign Attributes menu appears:

1. Authority Level
2. Access Group
3. User Partition
4. RF User Number
5. Pager On or Off

Refer to the system User Guide for assigning the appropriate user settings in the Assign Attributes Menu.

SINGLE BUTTON ARMING

If desired, the Arming Keys can be set for Single Button Arming by following prompts to store a valid user code in the keypad. (See the system User Guide for details on programming user codes.)

Enabling Single Button Arming

1. Press and hold down the **1 OFF** and **3** keys at the same time for 3 seconds. The screen displays the keypad's address.
2. Press ***** to move to the USER CODE entry screen.
3. Enter a valid four digit user code between 0000 – 9999 and press ***** to save and continue.

Recommended: Set a dedicated user code for this feature.

The user code must be entered for each keypad in the system where Single Button Arming is desired.

4. At the 'Delete Devices?' screen, press ***** to decline and exit.

Disabling Single Button Arming

1. Press and hold down the **1 OFF** and **3** keys at the same time for 3 seconds. The screen displays the keypad's address.
2. Press ***** to move to the USER CODE entry screen.
3. Enter **0** and then press ***** to save and move to 'Delete Devices?' screen.
4. Press ***** to decline and exit.

When Single Button Arming is disabled, a valid user code is required to arm the system with the Arming keys.

FUNCTION KEYS

The Function keys may be programmed by the installer for special functions or alarm activations. Key pairs may also be programmed for alarm activations.

To activate the Function keys, press and hold the key for at least 2 seconds; key pairs are activated immediately.

Check with the system installer for more information.

A or 1 OFF and *
B or * and #
C or 3 and #
D

COMMERCIAL STAY MODES

For commercial controls, if Stay Mode 2 is programmed, refer to the control's manuals and the table on the right for Stay mode arming.

Commercial Systems Stay Modes

STAY + 1 = Stay Mode 1
STAY + 2 = Stay Mode 2
NIGHT = Stay Mode 3 (both Stay 1 and Stay 2 modes)

SOUNDER

- Two-tone sound = burglary and audible panic alarms
- Pulsing sound = fire or carbon monoxide alarms

Refer to the system's user guide for details of audible notifications.

TROUBLESHOOTING

The error messages listed in the following table cause the keypad to produce a single ding tone. The table describes the error messages and the corrective actions.

Display	Corrective Action
KeyPd LB	Replace the battery in the wireless keypad.
Open Ckt	Contact your Installer.
Check 100	Contact your Installer.

FEDERAL COMMUNICATIONS COMMISSION (FCC) STATEMENTS

The user shall not make any changes or modifications to the equipment unless authorized by the Installation Instructions or User's Manual. Unauthorized changes or modifications could void the user's authority to operate the equipment.

Class B digital device Statement

This equipment has been tested to FCC requirements and has been found acceptable for use. The FCC requires the following statement for your information: This equipment generates and uses radio frequency energy and if not installed and used properly, that is, in strict accordance with the manufacturer's instructions, may cause interference to radio and television reception. It has been type tested and found to comply with the limits for a Class B computing device in accordance with the specifications in Part 15 of FCC Rules, which are designed to provide reasonable protection against such interference in a residential installation. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- If using an indoor antenna, have a quality outdoor antenna installed.
- Reorient the receiving antenna until interference is reduced or eliminated.
- Move the radio or television receiver away from the receiver/control.
- Move the antenna leads away from any wire runs to the receiver/control.
- Plug the receiver/control into a different outlet so that it and the radio or television receiver are on different branch circuits.
- Consult the dealer or an experienced radio/TV technician for help.

INDUSTRY CANADA CLASS B STATEMENT

This Class B digital apparatus complies with Canadian ICES-003.
Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

FCC / IC STATEMENT

This device complies with Part 15 of the FCC Rules, and ISSED's license-exempt RSSs. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Cet appareil est conforme à la partie 15 des règles de la FCC et exempt de licence RSS ISSED. Son fonctionnement est soumis aux conditions suivantes: (1) Cet appareil ne doit pas causer d'interférences nuisibles. (2) Cet appareil doit accepter toute interférence reçue y compris les interférences causant une réception indésirable.

The product should not be disposed of with other household waste. Check for the nearest authorized collection centers or authorized recyclers. The correct disposal of end-of-life equipment will help prevent potential negative consequences for the environment and human health.

The Honeywell Home Trademark is used under license from Honeywell International Inc. This product is manufactured by Resideo Technologies, Inc.

resideo

2 Corporate Center Drive, Suite 100
P.O. Box 9040, Melville, NY 11747
© 2020 Resideo Technologies, Inc.
www.resideo.com



800-11509V1B 7/13 Rev. B